HOW TO CONNECT

Is DRYMAX plugged into baler?

NO

This means that the applicator **is not communicating with the baler**. The main harness for the applicator will all run to the hitch of the baler.

Does the tractor have an ISO plug/terminal available?

NO

Order and connect 700964684 standalone kit

This kit will provide a standalone virtual terminal to communicate with the applicator and high-power connection to the battery. This would be used in applications when not used on an ISOBUS baler in a fully universal manner.

YES

Is tractor ISO plug connected to anything?

YES

NO

Connect DRYMAX directly into ISO plug on tractor

If the ISO plug is available on the back of the tractor, it can be used for access to high power applications and the virtual terminal. If this is the case, the applicator object pool will appear on the tractor virtual terminal.



YES

This means that the applicator **is communicating with the baler**. The main harness for the applicator will run to the hitch of the baler and to the back of the baler.



Is baler plugged into tractor ISO plug/terminal?

YES

Order and connect ACX5027560 Battery Harness

If the ISO plug is not available on the back of the tractor, then the customer will need to use an additional power harness to connect to the battery. If this is the case, the applicator object pool will appear on the standalone virtual terminal controlling the baler.

YES

Is baler plugged into standalone ISO kit?

NO

Call customer support or inside sales

NO

Does the tractor have an ISO plug/terminal available?

YES

Connect DRYMAX directly into ISO plug on tractor

If the ISO plug is available on the back of the tractor, it can be used for access to high power applications and the virtual terminal. If this is the case, the applicator object pool will appear on the standalone virtual terminal controlling the baler.

NO

AGCO PARTS